



Položka	Číslo dílu	Popis	Změn	Množstv	N/O	Možnost 1	Možnost 2	Poznámka
001	455252-2	FRONT COVER		1				
002	424528-8	SEAL		1				
003	187625-8	HOUSING SET		1				
D10		INC. 20						
004	142707-3	SWITCH PLATE COMPLETE		1	*			
004-1	143095-1	SWITCH PLATE COMPLETE	<	1				
005	450522-4	LENS		1				
006	632C23-4	BATTERY		1				
007	454080-2	COVER		1				
008	620175-5	CONTROLLER		1	*			
008-1	620453-3	CONTROLLER	<	1				
009	324885-3	HANGER		1				
010	232264-0	LEAF SPRING		1				
011	424367-6	RUBBER		1				
012	454077-1	FRONT COVER JOINT		1				
013	455028-7	BUTTON		1				
014	455027-9	STOPPER		1				
015	233344-5	COMPRESSION SPRING 4		1				
016	126231-4	MOTOR ASSEMBLY		1				
017	454084-4	FAN COVER		1				
018	424320-2	RUBBER RING		1				
019	423287-1	SPONGE SHEET 70-106		1	*			
019-1	424804-0	SUPONGE SHEET 76-110	<	1				
020	187625-8	HOUSING SET		1				
D10		INC. 3						
021	815T81-9	CL104D NAME PLATE		1				
022	266130-9	TAPPING SCREW BIND PT 3X16		8				
023	166084-9	DUST BAG		1				
024	141088-2	VALVE STAY COMPLETE		1				
025	424094-5	PACKING		1				
026	450521-6	INLET		1				
027	423444-1	SPONGE SHEET 52-76		2				
028	268271-7	PIN 3		1				
029	233580-3	TORSION SPRING 4		1				
A01	122861-9	NOZZLE ASS'Y		1	*			
C10	451410-8	ROLLER		4	*			
C20	268208-4	PIN 3		4	*			
C30	424096-1	WIPER		1	*			
A01-1	123485-4	NOZZLE ASSEMBLY	<	1				
C10	451410-8	ROLLER		4				
C20	268208-4	PIN 3		4				
C30	424096-1	WIPER		1				
A02	194566-1	PAPER FILTER SET (5PCS/SET)		1				
A03	416041-0	SASH NOZZLE (IVORY)		1				
A04	416043-6	SASH NOZZLE HOLDER (IVORY)		1				
A05	451424-7	PIPE		1				
A06	***DC1001	DC1001 BATTERY CHARGER SET		1				